



BRT test tubes – instruction manual heating block

Start of operation

- Connect power cord to 230 VAC mains
- Turn on „Netz“ mains switch, yellow LED „Heizen“ is on
- After 10 minutes the yellow LED „Heizen“ starts flashing, this also indicates that the temperature has reached 65.0 °C

Specification

Temperature: 65.0 °C +/- 0.1 °C
Voltage: 230 VAC, 30 watt